Headlights

▼ Type A





- 1 AUTO The headlights, side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on/off automatically in accordance with ambient light levels.
- The instrument panel, side marker, parking, tail, license plate and daytime running lights turn on.
- The headlights and all lights listed above turn on.
- 4 The daytime running light turn off.

▶ Type B





- 1 Auto The headlight, side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on/off automatically in accordance with ambient light levels.
- The instrument panel, side marker, parking, tail, license plate and daytime running lights turn on.
- The headlights and all lights listed above turn on.
- 4 The daytime running light turn off.

▶ Type C







- 1 O The daytime running lights turn on.
- 2 Auto The headlight, side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on/off automatically in accordance with ambient light levels.
- The instrument panel, side marker, parking, tail, license plate and daytime running lights turn on.
- The headlights and all lights listed above turn on.

To engage the high beams, push the lever forward. To flash the high beams temporarily, pull the lever toward you.

Automatic High Beam (If Equipped)

The Automatic High Beam uses an in-vehicle camera sensor to assess the brightness of streetlights, the lights of oncoming and preceding vehicles, etc., and automatically turns high beam on or off as necessary.





 $\begin{tabular}{ll} \hline 1 & Head light switch in "AUTO" position. \\ \hline \end{tabular}$




▶ Type B



 $\begin{tabular}{ll} \hline 1 & Head light switch in "AUTO" position. \\ \hline \end{tabular}$







When all of the following conditions are fulfilled, high beam will be automatically turned on (after approximately 1 second):

- Vehicle speed is above approximately 20 mph (32 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.

Windshield Wipers and Washer

■ Intermittent wiper with interval adjuster (if equipped)

▶ Type A





2 Intermittent operation

3 V Low speed

4 High speed5 Temporary operation



► Type B





- 1 OFF Off
- 2 INT Intermittent operation
- 3 LO Low speed
- 4 HI High speed
- 5 MIST Temporary operation





Intermittent operation: Wiper interval can be adjusted by turning the band.

- 6 Increases the intermittent windshield wiper frequency
- **7** Decreases the intermittent windshield wiper frequency

To spray washer fluid, pull the lever. The wipers will operate automatically.

■ Rain-sensing windshield wipers (if equipped)

▶ Type A





- 1 O Off
- 2 AUTO Automatic operation
- 3 Low speed
- 4 ¥ High speed

▶ Type B





- 1 OFF Off
- 2 **AUTO** Automatic operation
- 3 LO Low speed
- 4 HI High speed
- 5 MIST Temporary operation





Automatic operation: sensitivity can be adjusted by turning the band.

- 6 Sensor sensitivity (high)
- 7 Sensor sensitivity (low)

To spray washer fluid, pull the lever. The wipers will operate automatically.

Rear Window Wiper and Washer

▶ Type A





- 1 O Off
- 2 --- Intermittent window wiper operation
- 3 Normal window wiper operation
- 4 Washer/wiper dual operation
- 5 Washer/wiper dual operation

► Type B





- 1 OFF Off
- 2 INT Intermittent window wiper operation
- 3 ON Normal window wiper operation
- 4 Washer/wiper dual operation
- 5 Washer/wiper dual operation